



Air Tube Assembly




for 6-9

Size	Inflatable tube (L R)
6	01+02+03+06L+06R
7	01+02+03+07L+07R
8	01+02+03+08L+08R
9	01+02+03+09L+09R



for 10-14

Size	Inflatable tube (L R)
10	01+02+03+04+10L+10R
11	01+02+03+04+11L+11R
12	01+02+03+04+12L+12R
13	01+02+03+04+13L+13R
14	01+02+03+04+14L+14R



for 15-21

Size	Inflatable tube (L R)
15	01+02+03+04+15L+15R
16	01+02+03+04+16L+16R
17	01+02+03+04+17L+17R
18	01+02+03+04+18L+18R
19	01+02+03+04+19L+19R
20	01+02+03+04+20L+20R
21	01+02+03+04+21L+21R